



Cleaning & Maintenance Guideline

Indoor Rubber Tiles

A) Post Installation Cleaning:

- Clean tiles thoroughly with a high CFM vacuum to remove dirt or debris left from installation.
- The tiles are coated with a water-based release agent, a result of the manufacturing process. This will initially cause a slight slipperiness.
- For fast removal, damp mop with a solution of DinoClean or a neutral PH cleaner diluted in hot water.
 - Use a commercial microfiber mop. Be sure to mop with clean water to rinse away all detergent.
 - Use a two-bucket system and change water frequently.
- In rare circumstances, a more aggressive cleaning may be required to remove the release agent.
 - Use a high PH water-based cleaner such as Stoner A538.
 - The high PH will help emulsify the release agent, while detergents keep it in suspension allowing it to be rinsed away.
 - Apply undiluted A583 with a microfiber mop and let stand for 15 minutes.
 - The cleaned area should be rinsed using a light weight auto-scrubber with a soft nylon cylindrical brush, and warm, clean water.
 - An RPM of 185 and brush pressure between 35-80lbs are recommended.
 - The water must be extracted after this step to remove any remaining moisture. It is recommended to use a wet vac to extract moisture.

B) General Maintenance:

- Typically, Dinoflex Rubber Flooring requires less maintenance. Regular dry vacuuming is recommended with occasional damp mopping using a solution of warm water and DinoClean or a neutral PH cleaner.
- Use a two-bucket system with a commercial microfiber mop and change the rinse water frequently.
 - Do not use a string mop.



- While cleaning equipment/furnishings with a disinfectant or other strong cleaner, be careful that overspray or excess cleaner does not drip onto the rubber tiles.
 - Strong chemicals may cause the surface to deteriorate.
 - Products containing solvents and acids will attack the composite structure of the Stride Tile.
 - Dinoflex does not assume any responsibility for damages caused by chemical additives.
- For interlocking floors, one step machines are not appropriate. Only use equipment that extracts dirty water as it cleans.

C) Deep Cleaning

- In areas of high traffic, a more aggressive cleaning may occasionally be required because of a build up of dirt.
- A steam vacuum is ideal for deep cleaning.
 - If required DInoClean or a neutral PH cleaner can be used with this equipment.
- Do not flood floor when using this equipment.
- It is important to use equipment that removes all liquids during the process.
- If necessary, tiles may be removed and cleaned thoroughly.
 - Be sure that tiles are completely dry and free of foreign material before reinstalling.

For additional information, please contact your Dinoflex Sales Representative, or for additional technical assistance, contact Dinoflex Recycled Rubber Innovators.

Dinoflex Recycled Rubber Innovators
 P.O. Box 3309
 5590 – 46th Ave S.E.
 Salmon Arm, B.C. V1E 4S1 Canada

Tel: (250) 832-7780
Fax: (250) 832-7788
Toll Free: 1-877-713-1899
E-mail: sales@dinoflex.com

www.dinoflex.com

